RM050A-R2
RM051A-R2

BLACK BOX
NETWORK SERVICES

Ultra Wallmount Racks User's Manual

Mount heavy equipment in tight spaces.

Customer Support Information

Order toll-free in the U.S.: Call 877-877-BBOX (outside U.S. call 724-746-5500)
FREE technical support 24 hours a day, 7 days a week: Call 724-746-5500 or fax 724-746-0746
Mailing address: Black Box Corporation, 1000 Park Drive, Lawrence, PA 15055-1018
Web site: www.blackbox.com • E-mail: info@blackbox.com

Trademarks Used in this Manual

Black Box and the Double Diamond logo are registered trademarks, and Elite is a trademark, of BB Technologies, Inc.

PLEXIGLAS is a registered trademark of Roehm GmbH & Co.

UL is a registered trademark of Underwriters' Laboratories.

VELCRO is a registered trademark of Velcro Industries B.V.

Any other trademarks mentioned in this manual are acknowledged to be the property of the trademark owners.

We're here to help! If you have any questions about your application
or our products, contact Black Box Tech Support at **724-746-5500**
or go to **blackbox.com** and click on "Talk to Black Box."
You'll be live with one of our technical experts in less than 30 seconds.

Table of Contents

Preface 4
Safety Symbols Used in This Manual 4
Safety Considerations 4

1. Specifications 5
1.1 Size 5
1.2 General 5
1.3 RM050A-R2 Drawings 6
1.4 RM051A-R2 Drawings 9

2. Overview 12
2.1 Introduction 12
2.2 Features 12
2.3 What's Included 12

3. Mounting Instructions 13
3.1 Receiving, Unpacking, and Removing the Ultra Wallmount Rack from the Carton 13
3.2 Wood Studded Wall 13
3.3 Masonry Wall Surface 13
3.4 Loading Equipment 14
3.5 Power 14
3.6 Protective Grounding 14
3.6.1 Connecting the Main Protective Grounding Stud to the Dedicated Branch Circuit Grounding Conductor 14
3.6.2 Connecting the Main Protective Grounding Stud to the Protective Bonding Conductors 14

Preface

This manual is provided to prevent service personnel from committing an act that results in the risk of fire, electric shock, or injury to persons. Only trained service personnel should receive, unpack, and assemble the Ultra Wallmount Rack. In addition, only trained service personnel should install equipment in the rack.

Safety Symbols Used in This Manual

This manual provides general safety guidelines to be observed during installation, operation, and maintenance of the Ultra Wallmount Rack.

WARNING: Failure to follow directions in the warning could result in injury to persons or loss of life.

CAUTION: Failure to follow directions in the caution could result in damage to equipment or storage data.

Safety Considerations

WARNING: Improper handling and use of the Ultra Wallmount Rack could result in equipment damage, serious injury, or possible death.

Only trained service personnel should be used to remove the rack from the carton. Also be sure you have a sufficient number of service personnel. Do not attempt to move racks by yourself.

Only UL® Listed ITE units should be installed in the Ultra Wallmount Rack.

Be sure to read and follow all individual manufacturer equipment manuals for safety and installation instructions.

Proper spacing is required when installing electrical equipment to avoid electrical shock.

1. Specifications

1.1 Size

Table 1-1 lists specifications for the rack shown in Figures 1-1 through 1-10.

Table 1-1. Rack size specifications.

Part Number	#of RUs	Height	Width	Depth
RM050A-R2	11	23.57" (59.86 cm)	19.8" (50.3 cm)	25" (63.5 cm)
RM051A-R2	19	35.57" (90.34 cm)	19.8" (50.3 cm)	25" (63.5 cm)

1.2 General

Cable Openings (Bottom Plate) — 3" diameter

Certifications: UL® Listed

Construction:
Baseplate: 14-gauge steel;
Sides: 11-gauge steel;
Rails: 11-gauge steel

Finish: Black powder coat

Grounding: Ground studs located on rear and middle sections

Mounting Hardware — ¼" diameter

Rail Type: 12-24 tapped

Weight Capacity: 150 lb. (68 kg)

1.3 RM050A-R2 Drawings



Figure 1-1. RM050A-R2.

Table 1-2. RM050A-R2 components.

Number*	Quantity	Description
1	1	Swing rack base plate
2	1	Top/bottom brace
3	4	Bolt, ⅜"-16 x ½"hex head, gr 2, steel, black
4	4	Socket head shoulder set screw
5	4	¼"-20 x ½"L hex head screw
6	2	21.258"H x 25"D swing rack side weldment
7	1	21"H reinforced swing frame weldment
8	4	Nut, ¼-20, steel, grade 2, zinc plated

**NOTE: The numbered components in Table 1-2 refer to Figure 1-1.*



Figure 1-2. RM050A-R2 assembled view.



Figure 1-3. RM050A-R2 front view.



Figure 1-4. RM050A-R2 right side view.



Figure 1-5. RM050A-R2 top view.

1.4 RM051A-R2 Drawings



Figure 1-6. RM051A-R2.

Table 1-3. RM051A-R2 components.

Number*	Quantity	Description
1	1	35"H reinforced swing frame weldment
2	2	32.258"H x 25"D swing rack side weldment
3	1	Top/bottom brace
4	4	Bolt, ⅜"-16 x ½" hex head, gr 2, steel, black
5	4	Socket head shoulder set screw
6	4	¼"-20 x ½"L hex head screw
7	1	Swing rack base plate
8	4	Nut, ¼-20, steel, grade 2, zinc plated

**NOTE: The numbered components described in Table 1-3 refer to Figure 1-6.*



Figure 1-7. RM051A-R2 assembled view.



Figure 1-8. RM051A-R2 front view.



Figure 1-9. RM051A-R2 right side view.



Figure 1-10. RM051A-R2 top view.

2. Overview

2.1 Introduction

Ultra Wallmount Racks are designed to securely hold 19" rackmount equipment, networking equipment, phone equipment, etc. in tight spaces or closets.

2.2 Features

- 25" depth provides plenty of rooom to open and close the rack, even when fully loaded with patch panels, hubs, or routers.
- Reinforcement base plate.
- Welded steel frame.
- Can be reversed to open left or right.

2.3 What's Included

Your package should include the following items. If anything is missing or damaged, please contact Black Box Technical Support at 724-746-5500 or info@blackbox.com.

- Swing rack base plate
- Top/bottom brace
- (4) ⅜"-16 x ½" hex head bolts, black
- (4) socket head shoulder set screws
- (4) ¼"-20" x ½" hex head screws
- (4) ¼"-20" nuts, grade 2, zinc-plated
- (2) swing rack sides
- (1) swing frame
- (30) 12-24 mounting screws
- Mounting hardware for wood studded wall only, including (4) ¼"-10" x 2" lag bolts, (4) flat washers, and (4) locking washers
- Bonding and grounding system with (1) ground jumper

3. Mounting Instructions

3.1 Receiving, Unpacking, and Removing the Ultra Wallmount Rack from the Carton

Inspect for damage and report damage if there is damage before receiving. Refer to Section 2.3 for what's included in the package.

Unpack the rack by carefully removing the corrugated carton and corners. Avoid damaging the enclosure when removing packaging.

WARNING: Only trained service personnel should be used to remove the rack from the carton. Also be sure you have a sufficient number of service personnel. Do not attempt to move racks by yourself.

WARNING: Be careful when moving racks before installation. Sudden stops and starts, excessive force, obstructed routes, and uneven floor surfaces may cause the rack to topple over.

3.2 Wood Studded Wall

Once the location on the wall has been determined, inspect the wall surface. The wall must be flat and square in the horizontal and vertical plane to ensure the Ultra Wallmount Rack closes correctly. If the wall is not flat and square, you might need to use shims.

Wood studded wall mounting instructions apply to a 2" x 4" wood stud wall with ¾" plywood. To make installation easier, use the back section of the Ultra Wallmount Rack by loosening the 10-32 screws in the rear hinge. Use the back section of the Elite Wallmount as a template for locating the ¼-20 lag bolts and washers.

Once you locate the lag bolts, you can mount the back section to the wall and secure it with the ¼-20 lag bolts and washers.

WARNING: Improper handling and use of the Ultra Wallmount Rack could result in equipment damage, serious injury, or possible death.

3.3 Masonry Wall Surface

For a masonry wall surface, the installer must provide the appropriate hardware.

3.4 Loading Equipment

WARNING: Only install equipment after the Ultra Wallmount Rack has been properly secured and mounted to the wall.

Maximum Load Capacity

The rated or maximum load capacity for the Ultra Wallmount Rack is 150 pounds.

3.5 Power

When using power distribution units (PDUs), each PDU should be connected to a committed branch circuit that is rated for the continuous load of all the connected equipment.

When not using a PDU, each piece of equipment should be connected to a dedicated branch circuit.

3.6 Protective Grounding

A main protective grounding stud and grounding studs are provided along with grounding jumper wires that electrically bond the swing frame doors to one of the swing rack sides.

WARNING: To avoid injury to persons or loss of life, ground each enclosure individually to the dedicated branch circuit earthing ground.

3.6.1 Connecting Main Protective Grounding Stud to the Dedicated Branch Circuit Earthing Ground Conductor

Connect the dedicated branch circuit ground conductor to the main protective grounding stud located at the rear of one of the swing rack sides.

3.6.2 Connecting Main Protective Grounding Stud to the Protective Bonding Conductors

Connect the swing frame to the grounding stud located at the front of one swing rack side using a listed ring or closed-loop terminal.

Black Box Tech Support: FREE! Live. 24/7.



Great tech support is just 30 seconds away at 724-746-5500 or blackbox.com.

BLACK BOX®
NETWORK SERVICES

About Black Box

Black Box Network Services is your source for an extensive range of networking and infrastructure products. You'll find everything from cabinets and racks and power and surge protection products to media converters and Ethernet switches all supported by free, live 24/7 Tech support available in 30 seconds or less.

© Copyright 2011. All rights reserved.

RM050A-R2, rev. 2